



NLDX2.E467959 Motor Controllers, Magnetic - Component

[Page Bottom](#)

Motor Controllers, Magnetic - Component

[See General Information for Motor Controllers, Magnetic - Component](#)

RELAYGO COMPONENTS S L

E467959

Polígono Industrial Urtinsa
Calle La Laguna 30
28923 Alcorcon, SPAIN

Investigated to ANSI/UL 508

Accessories, Bridge Bars Model(s) Cat. No. BF14, followed by G, B or R to indicate color.

Accessories, Contact Terminal Bridge Model(s) Cat. Nos. BF31 and BF34, followed by B, G or R; Bobbin Terminal Bridge, Cat. No. BF24 followed by B, G or R.

Magnetic motor controller Model(s) Type FG followed by 5610, 5611, 5618, 5625, 5626, 5627, 5628, 5629, 5633, 5640, 5649, 5658, 5659, 5661 or 5664.

Type FG-5453 may be followed by a D or DX, followed by "/", followed by 300? or 640?.

Type RF followed by 1 or 2, followed by 0, 1, 2, 3, 4 or 5, may be followed by 10, 14, 17, 22, may be followed by N or L, may be followed by D, E, N, R, U, X or Y, may be followed by any one number, may be followed by any one letter, followed by any suffix 005-110 Vdc or 006-240 Vac.

Type RM followed by 1, 2 or 3, followed by 0, 1, 2, 3, 4 or 5, may be followed by 10, 11, 12, 13, 14 or 19, may be followed by N or L, may be followed by D, E, N, R, U, X or Y, may be followed by any one number, may be followed by any one letter, followed by any suffix 005-220 Vdc or 006-250 Vac.

Magnetic Motor Controller Model(s) Type RM followed by 1, followed by 0, 1, 2, 3, 4 or 5, may be followed by 15 or 16, may be followed by N or L, may be followed by D, E, N, R, U, X or Y, may be followed by any one number, may be followed by any one letter, followed by any suffix 005-220 Vdc or 006-250 Vac.

Magnetic motor controller Model(s) Type RP followed by 1, 2 or 3, followed by 0, 1, 2, 3, 4 or 5, may be followed by 10, 15, 16, 25, 26 or 27, may be followed by N or L, may be followed by D, E, N, R, U, X or Y, may be followed by any one number, may be followed by any one letter, followed by any suffix 005-220 Vdc or 006-400 Vac.

Type RQ followed by 2 or 4, followed by 0, 1, 2, 3, 4 or 5, may be followed by 10, 12, 17 or 19, may be followed by N or L, may be followed by D, E, N, R, U, X or Y, may be followed by any one number, may be followed by any one letter, followed by any suffix 005-110 Vdc or 006-240 Vac.

Relay sockets Model(s) Cat. Nos. SMB20D, SMB30D or Cat. Nos. RS-403.213, RS-403.299

Cat. Nos. SMT20D, SMT30D, SMT20J, SMT30J, SPT30D and SPT30J

Cat. Nos. SQB20D, SQB20I, SQB40D, SMB30P, SFB10D, SFR10D, SFP10X, SFB20D, SFP20X, RS-341.6874, RS-437.777, RS-437.783 and RS-437.799.

Solid State Relays Model(s) Type RS followed by 1614, 1714, 1814 or 1914.

Marking: Company name and model designation.

[Last Updated on 2015-06-09](#)

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".